



Powder Puff Pilot PNR Headset

Operating Instructions

To operate your PNR headset:

1. Rotate the flexible microphone boom to transmit from the right or left.
2. Before plugging into the intercom or aircraft, rotate the headset volume control (on the side of the headset opposite the microphone boom) fully counter-clockwise to the minimum position.
3. Rest the headband securely on the top of your head, with the earseals centered over your ears.
For more tips on achieving a comfortable fit, see p 2.)
4. For best noise cancellation, position the microphone no more than ¼ inch (6 mm) from your lips.
5. Insert the microphone plug (PJ068) earphone plug (PJ055) into their respective aircraft or intercom jack.
6. Rotate the headset volume knob clockwise to a comfortable level.
7. Set the mono/stereo switch on the battery module to mono or stereo.

Cautions

Proper fit is critical to the PNR model's noise attenuation effectiveness. To ensure proper fit of your PNR headset:

- Push the headband down until it rests comfortably on the top of your head.
- Move the earcups slightly up or down or from side to side until you achieve maximum attenuation.
- Since eyeglasses reduce attenuation, wear eyeglasses with thin temples to minimize noise leakage.

To keep your headset working properly:

- Never alter your headset.
- If you see a defect such as splits in cups, seek immediate replacement.

To clean your headset:

- Do not immerse in water.
- Clean regularly with mild soapy water. Sponge off the headpad and earseals, taking care to rinse thoroughly.